
# **PEARL DRUM PEDAL**




## **Instruction Manual**

Congratulations on your purchase! To get optimum performance of your Pedal, please read this Instruction Manual before playing.




**DUO BEAT (2-Surface Beater)** The Duo Beat has two Surfaes, each capable of producing a different sound. Please refer to the following chart to determine the sound best suited your playing style. (Fig. A)




### **BEATER SETTING**

Locate the Beater Holder Link and Key Bolt. Insert the shaft of the Duo Beat into the Beater Holder Link and tighten the Key Bolt to secure the beater at the desired height.Experiment with different beater heights to find the best combination of power and speed.(Fig.B)




#### BEATER ANGLE ADJUSTMENT

Depending on your preference, the beater can be positioned closer or further away from the bass drum head. This is accomplished by loosening the Key Bolt on the Beater Angle Cam and swinging the beater to the desired angle. Re-tightening the Key Bolt. (Fig. C)




#### SPRING TENSION ADJUSTMENT

To increase the tension of the spring, loosen the Upper Nut and tighten the Lower Nut until the desired tension is achieved. To decrease the tension, loosen the Lower Nut. This adjustment assembly employs a double nut system to retain tension settings. Before playing, make sure that both nuts are tight. (Fig. D)



#### HOOP CLAMP WING BOLT

Place the pedal on the bass drum hoop and tighten the Wing Bolt to clamp the pedal firmly in place. (Fig. E)



	lically check all Allen Screws for
tightne	ess and tighten them with the
provid	ed Allen Wrenches as needed.
Period	lically apply lube to all moving
parts s	such as the Chain, Cam Roller,
Footbo	pard Hinge, etc. for optimal
	and extended life of your
, pedal.	Bearings should be lubricated
	rease, not liquid oil.

